



# How to Use the Premium Gas Stove

## Operation




## Turning On and Off




### 1. Press the [Power button] for 1 second.

- The LED on the lock settings display is illuminated, and the – indicator on each burner's heat power display is illuminated.




### 2. Press the [Lock button] to disable safety lock.

- The lock settings display LED turns off.
- The safety lock feature is for safety and reactivates for every initial operation.



### 3. Press the [On/Off button] you want to use to start ignition.

- Use the [Heat power Control button] to set the heat from level 1-9.




### 4. Press the [On/Off button] for the burner you want to turn off. The burner turns off and the “–” indicator appears on the heat display.


### 5. Press the [Power button] to turn off the power.

- If all burners are off, the stove will automatically turn off after 20 seconds even if the Power button is not pressed.
- You can turn off all burners by pressing the [Power button] during operation.


# Timer Settings (Left and Right Large Burners)



1. Once the burner you want to use is on, set your desired heat.




2. Press the burner's [Timer Selection button] once the heat power is set.



3. Press the [Timer Settings button] to set your desired time.

- You can set it from 0-99 minutes.
- Press and hold the [Timer Settings button] during setup to quickly change the time in intervals of 10 minutes.
- Press the [Timer Selection button] once more or wait 5 seconds for the timer to work automatically.



4. When using timers for both the left and right burners, press the [Timer Selection button] to check the time each burner has left.

5. Press the [Timer Selection button] for 3 seconds while the timer is operating to turn it off.